



Grocery List

Ingredients

1/2 cup butter - softened

1/4 cup packed brown sugar

1/4 cup sugar

1 teaspoon vanilla extract

1 egg + egg white

2 1/2 cups Almond Flour

1 cup choc chips

1/2 teaspoon baking soda

1/4 teaspoon salt

Prep

1. Preheat oven 350°

2. Beat together

butter, sugar + vanilla

then beat in Eggs

3. Stir in Almond flour

baking soda + salt

4. Stir in choc chips

Bake 12 to 15 min

or until lightly
browned on top

